



Ref. Part Description 14070H

UPPER ASSEMBLY

3	Fulcrum Kit	177420
1	Fulcrum Pin	(100348)
2	Arm Washers (2)	(100163)
4	Arm Spring Assembly	177531
5	Arm Spring	(100349)

NOZZLES (Specify nozzle size when ordering)

6	Straight Bore	105842xx
6	Straight Bore W/ Vane	106131xx
-	Vane	105816
7	Spreader 7 Degree	100225xx
7	Spreader 20 Degree	100226xx
7	Brass Plug (W Models)	100255

BEARING ASSEMBLY

8	Bearing Assy (H Style)	177424
10	Top Seal Washer (Grn)	(103709)
11	Metal Top Seal Washer	(100312)
12	Bearing Spring	(106237)
13	Bearing Sleeve	177510
14	Bearing Washer (Black)	(100726)
15	Wear Washer (Orange)	(103058)
16	Seal Washer (Gray)	(102345)
17	Bearing Nipple	177517
9	Bearing Washer Kit	177447
10	Top Seal Washer (Grn)	(103709)
11	Metal Top Seal Washer	(100312)
12	Bearing Spring	(106237)
14	Bearing Washer (Black)	(100726)
15	Wear Washer (Orange)	(103058)
16	Seal Washer (Gray)	(102345)

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.